



DE

Anleitung

EN

Instruction



ZUR BEACHTUNG UND WARNUNG



GE
Bemerkung: Bitte lesen Sie die gesamten Sicherheitsvorgaben und Warnungen und die Montageanleitung vor der Montage.

ACHTUNG! Enthält Kleinteile! Erstickungsgefahr! Bitte achten Sie darauf, dass Kinder die Kleinteile nicht in den Mund nehmen, beim Verschlucken besteht Erstickungsgefahr. Dieses Produkt ist kein Spielzeug.

Kleine Kinder können sich in den Kordeln zur Betätigung der Rollos strangulieren. Kordeln sind aus der Reichweite von Kindern zu halten, um Strangulierung und Verwicklung zu vermeiden. Betten, Kinderbetten sowie Möbel sollen entfernt von Kordeln für Fensterabdeckungen aufgestellt werden. Binden Sie die Kordel nicht zusammen und stellen Sie sicher, dass sich die Kordel nicht verdreht und eine Schlinge bildet.

Wenn Sie die Balance verlieren, halten Sie sich nicht an der Kordel fest. Die Kordel kann zerreißen oder abreißen. Nur an einem geeigneten Fensterrahmen montieren! Im Zweifel fragen Sie einen Fachmann.

Reinigung: Nicht mit säure- oder lösungsmittelhaltigen Reinigungsmitteln, Scheuermitteln oder scheuernden Reinigungsgeräten reinigen. Wischen Sie das Rollo mit einem weichen trockenen Tuch ab.

Der Sicherheitsclip sollte hoch genug positioniert werden um außerhalb der Reichweite von kleinen Kindern zu sein aber dennoch von Erwachsenen erreichbar sein. Empfohlene Montagehöhe ca. 1,5 m. Der Sicherheitsclip sollte mit einer entsprechenden Schraube fest am Fensterrahmen montiert und nicht nur angeklebt werden. Falls die Kordel zerreißt, entfernen Sie die Kugeln aus der Reichweite von Kindern, beim Verschlucken besteht Erstickungsgefahr.

Stellen Sie sicher, dass die Kordel straff gespannt ist! Der Halteclip muss in der größtmöglichen Entfernung befestigt werden, so dass die Kordel nicht durchhängt. Kinder können sich strangulieren, wenn diese Sicherheitsvorrichtung nicht ordnungsgemäß installiert wird. Nutzen Sie den

Sicherheitsclip um die Kordel außerhalb der Reichweite von Kindern zu halten.

Lesen Sie diese Anleitung aufmerksam durch und montieren Sie den Artikel entsprechend.

EN

Remark: Please read all safety warnings and installation information fully before installation.

Make sure children do not put any assembly part in the mouth, they could swallow the parts and choke. This product is not a toy.

Young children can be strangled by slings in pull cords, chains, straps and internal cords intended for operating the product. To avoid strangulation and entanglement, keep cords out of the reach of children. Cords may become wrapped around a child's neck. Place beds and children's furniture away from bund cords. Move cribs and furniture away from window covering cords. Do not tie together, make sure cords do not twist and create a loop.

If you lose your balance, do not hold on to the chain or bund. The chain could break or the bund could be pulled out of bracket. Only mount the bund on a suitable window frame. If necessary, consult a professional.

Cleaning instruction: Do not use any acid content detergent or solvent or any abrasives or steel wool! Brush or wipe dry with a soft cloth.

The safety clip should be positioned high enough (1.5m) to keep out of reach of children while remaining accessible to adults. All the safety clips should be fixed solidly to surfaces with suitable screw and to the fixed equipment. They should not be fixed with glue. If the small chain break, we recommend your greatest vigilant to the ball of the chain that are scattered and ingested by children which may cause asphyxiation.

Please make sure that the chain fix tightly, it must be installed at the maximum distance possible mechanism so that it does not loose. Children could strangle if this device is not installed well. Always use this device to keep cords or chains out of reach of children. Children can strangle if this safety device is not installed. Always use this device to keep cords or chains out of the reach of children.

Read carefully the instruction and install accordingly.



